




AdvantagePlus Troubleshooting

When first diagnosing an AdvantagePlus, check the following:

- If the unit is not operating, is the power on?
- Is the unit gas valve turned on?
- Is the unit thermostat temperature setting high enough to call for heat?
- What is the temperature of the water in the tank?
- Is there "LOC" in the LED panel window? (Press red reset button on front panel. Allow retrying for ignition. Then diagnose based on the table below.)


LINE LED is off; does not have 120VAC


Explanation: This LED monitors incoming AC line voltage. The LED is ON when 120VAC line voltage is present on the control board. If the wall plug is properly wired, you will see a green LED light on the bottom left hand corner of the control board.



At a minimum, check the following:

1. Plug in unit; check circuit breaker
2. Polarity is correct or ground is missing on wall plug
3. Re-seat CN1 Molex plug on control board
4. Verify display ribbon cable is connected to main board and display board








24 VAC LED is off; does not have 24VAC out of the transformer




Explanation: This LED monitors voltage from the transformer. The LED is ON when secondary 24VAC is present. You may have line voltage and not have the 24VAC line lit if the board is bad.

At a minimum, check the following:
 Transformer wiring
 Reseat plugs on control module (CN4)





ECO/VENT SWITCH; Water in tank is too hot or vent gas is too hot or low water cut off switch has tripped





Explanation: This LED monitors the ECO loop in the tank water, the low water cut off switch and the vent over temperature switch. LED is ON when all three of these safety devices are normal. The loop is electrically closed.


At a minimum, check the following:

1. Water temperature
2. Vent temperature at exhaust coupling
3. Low water level in tank


Follow this process in sequence: Recycle power to the water heater. If the blower does not come on, go to step #1; if the blower does come on, go to step #2.








PRESSURE SWITCH; Air pressure switch or blower motor not operating properly; problem with venting.




Explanation; Monitors the positive air pressure switch. Means there is sufficient combustion airflow. The LED is ON when the pressure switch is closed. Fault indicates insufficient airflow thru the venting and blower system.

At a minimum, check the following:


1. Venting blockage (air in and air out)
2. Blower not operating
3. Pressure switch stuck open
4. Vinyl tubing to pressure switch is kinked






Venting Related Questions

1. Is the unit vented with the proper 2" or 3" piping as required by the BTU input?
2. How many elbows/angles in the exhaust pipe?
 - a. See the vent table in the Installation Manual for equivalent footage impact.
3. How many elbows/angles in the combustion air pipe?
 - a. See the vent table in the Installation Manual for equivalent footage impact.
4. How many feet of pipe in the exhaust?



- a. Equivalent footage for combustion air and exhaust may not exceed the specified limitations in the vent table.
- 5. How many feet of pipe in the combustion air?
 - a. See the vent table in the Installation Manual for equivalent footage impact.
- 6. How is the venting system terminated?
 - a. Two pipe, concentric vent kit, or V-1000 aluminum kit. See the Use and Care Manual for examples of proper vent termination on the exterior wall or roof.
- 7. Are both the combustion air and exhaust terminated on the same plane?
- 8. Is the separation, and offset within specification for a two-pipe termination?
 - a. See the Use and Care Manual for examples of proper vent termination on the exterior wall or roof.
- 9. Is the coupling on the exhaust, and the tee on the combustion air and oriented correctly?
 - a. A concentric vent assembly must have every joint glued, or exhaust will contaminate the combustion air. Is the "Y" on the concentric vent horizontal termination only pointing up perpendicular to the ground?
 - b. If using the V-1000, the combustion air pipe must be butted to the "L" bracket spot welded to the inside of the vent assembly cover, and the exhaust pipe glued to the exhaust coupling in the vent assembly cover.
- 10. Is the termination adjacent to an inside vertical corner, or roof overhang? Is it within 3 feet of either?
 - a. This will cause the combustion gases to re-circulate back in to the fresh air intake.
- 11. Is the termination behind bushes or shrubs?
 - a. This will cause the combustion gases to re-circulate back in to the fresh air intake. And it will kill the shrubs.
- 12. If the termination is horizontal, is there a wall or other vertical obstruction within 4' of the exhaust line of travel?
 - a. This will cause the combustion gases to re-circulate back in to the fresh air intake.
- 13. Are all horizontal exhaust pipe runs pitched 1/4" to the foot back to the heater?
- 14. Is the pipe supported so there are not traps for condensate in the exhaust?
- 15. Is the exhaust pipe pitched upward when exiting the no hub fitting on the unit?
 - a. This point almost always seems to get pitched down because they don't support that short piece of pipe between the no hub fitting and the first elbow. The elbow becomes a trap for water, thus adding equivalent footage to the vent.

GAS VALVE; no flame rectification; maximum ignition attempts.




Explanation: The LED is ON when power is applied to the gas valve. Controls are looking for flame rectification, meaning there is main burner. Unit will make three successive trials; then lock out

At a minimum check the following:

1. Gas valve shut OFF
2. Broken or corroded flame sensor wire
3. Connectors on control panel unplugged
4. Tubing between valve and air inlet is present
5. Unit has proper service pressure
6. Gas fuel supply or piping problem
7. Gas valve improperly adjusted
8. Verify green polarity light on board





Gas Supply Related Questions:


1. What is the Utility Co. meter capacity compared to the total connected gas load?
 - a. Must be of adequate capacity to handle total load. This includes meter and meter regulator serving building gas distribution.
2. Is the service a 5 pound, 2 pound, or inches WC service?
 - a. If the service is a 7" WC service, it is most unlikely there will be 7" WC operating gas pressure at the unit.
3. Is there an in-line appliance regulator serving the AdvantagePlus?
 - a. How far up stream is the in-line appliance regulator from the AdvantagePlus?

- b. What size is the pipe between the appliance regulator and the AdvantagePlus 3/4 inch x 1/2 inch factory installed reducing coupling?
 - c. Most of the time these regulators are installed too close to the unit. They must be upstream 10', and minimum 3/4" ID black steel pipe run all the way to the 3/4" x 1/2" factory installed reducing coupling. No flex connectors allowed, except a Dormont 3/4" ID commercial grade connector.
 - d. What is the BTU capacity of the in-line appliance regulator?
4. The gas supply regulator must be of sufficient size to accommodate all gas products it will service. If you have two 100,000 BTU heaters, then the regulator must be capable of supplying a minimum of 200,000 BTUs of fuel.
 5. Is the in-line regulator vented to the atmosphere?
 - a. If not, is the regulator equipped with a "vent limiter"?
 - b. In our experience some regulators are prone to field problems with inconsistent regulator performance. They have vent-limiting devices, and do not respond well.
 6. Verify the gas orifice is installed, and it is the correct orifice for the gas in use.
 7. Is there a fabricated drip leg to keep debris out of the gas valve?

Adjust the AdvantagePlus using a CO meter. CO above 10 parts per million will cause premature igniter failure, premature burner failure, and huffing and puffing sounds.

Many installations on natural gas are victims of insufficient gas volume due to inadequate gas available on the job. Meter sizing, and building distribution piping, more often than not, is the culprit. In addition, CSST (Corrugated Stainless Steel Tubing) is a major problem! This material may be used only on 2-pound systems to supply high-pressure gas to the appliance regulator, assuming it is properly sized for the job. The low-pressure gas from the regulator to the AdvantagePlus must be 10 feet of 3/4" ID black steel pipe.



Igniter; Power to igniter




Explanation: Monitors igniter element output. The LED is ON when 120VAC power is applied to the igniter.


At a minimum, check the following:

1. Igniter current draw is too low.
2. Molex is connected.





Combustion Blower; Power to blower




Explanation: If the blower motor fails, then the **PRESSURE SWITCH** indicator light will blink. The **COMB BLOWER LED IS** on when power is supplied to the blower motor.

At a minimum check the following:

1. Molex connections are tight on the board
2. Molex connects are tight on the blower






You must perform BOTH tests to determine if the blower motor or control board is bad. Unit must PASS both tests to verify the blower motor is bad; or FAIL one test to determine the main control board is bad.

Things to remember:

- A. The main pc control board passes the 120VAC to the motor. There is NOT a direct link to the line voltage except through this board.**
- B. If you have 120VAC on plug CN1, you must have 120VAC on the plug CN4 or the pc board is bad.**
- C. You must perform all tests to determine if the blower motor or pc control board is good or bad.**

WATER TEMPERATURE; problem with the water temperature probe or the water temperature





Explanation: This is the thermistor that monitors the water temperature inside the tank. The LED is ON when the water temperature drops below the set point on the LED panel. If the water temp LED is ON, then the unit should be in main burner or attempting to fire off.

At a minimum check the following:


1. Temperature probe wiring is unplugged
2. Probe open internally
3. Probe wiring shorted
4. Probe shorted internally
5. Thermostat set point is OK. See resistance chart at end of this document

6. If the display reads “255”, then the temperature probe is damaged and needs replacement




If the unit is operating, but not holding temperature, verify the flow rate of water is within the GPM performance for the temperature rise. If flow is not the problem, look at the ECO/Temperature probe. There may be a hole in the probe allowing water into the electronics, thus causing a false signal.

CONTROL HEALTH; problem with the control self diagnosis



CONTROL HEALTH and GAS VALVE; failed to establish main burner after 3 successive attempts



Explanation: The unit will make three attempts for main burner, then locks out. This is probably associated with a fuel supply problem.


At a minimum, check the following:


1. Gas valve ON
2. Gas valve connector Molex is firmly seated.
3. Wires to this Molex are firmly seated into the connection itself.
4. Recycle power by pushing the red button.

INTEGRATED WATER HEATER CONTROL
1200 BOARD SYSTEM

REPLACEMENT PARTS IDENTIFICATION		
ITEM	DESCRIPTION	HTP PART NUMBER
1	TRANSFORMER & BLOWER SUPPLY CABLE	7000-666
2	CONTROL BOARD - MUST SPECIFY MODEL & SERIAL NUMBER WHEN ORDERING	7000-702
3	DISPLAY BOARD	7000-664
4	DISPLAY BOARD TO CONTROL BOARD WIRE	7000-665
5	PRESSURE SWITCH	7250P-150
6	WIRE HARNESS FROM CN6 TO GAS VALVE, FLAME PROBE AND PRESS. SWITCH	710B0041
7	WIRE HARNESS FROM CN1 TO LINE POWER	710B0048
8	WIRE HARNESS FROM CN2 TO COMBUSTION BLOWER & TRANSFORMER	7000-666
9	ECO/TEMPERATURE PROBE (WIRED TO CN3)	WHC1001-ECO-1
*10	PUSH BUTTON SWITCH FOR IGNITOR & FLAME CURRENT	7000-667
11	LOW WATER CUT-OFF SENSOR ASSEMBLY (FOR 80 AND 119 GAL. ONLY)	7000P-852

*NOT SHOWN





Temperature °F	Ω Resistance
70	11,884
71	11,593
72	11,308
73	11,031
74	10,764
75	10,501
76	10,249
77	10,000
78	9,762
79	9,526
80	9,300
81	9,078
82	8,862
83	8,653
84	8,448
85	8,251
86	8,056
87	7,869
88	7,685
89	7,507
90	7,333
91	7,164
92	6,999
93	6,838
94	6,683
95	6,530
96	6,383
97	6,238
98	6,098
99	5,961
100	5,827
101	5,698
102	5,571
103	5,449
104	5,327
105	5,210
106	5,095
107	4,984
108	4,876
109	4,769
110	4,666

Temperature °F	Ω Resistance
111	4,564
112	4,467
113	4,370
114	4,277
115	4,185
116	4,096
117	4,008
118	3,923
119	3,840
120	3,759
121	3,681
122	3,603
123	3,529
124	3,455
125	3,383
126	3,313
127	3,244
128	3,178
129	3,112
130	3,049
131	2,986
132	2,926
133	2,866
134	2,809
135	2,752
136	2,697
137	2,643
138	2,590
139	2,539
140	2,488
141	2,439
142	2,391
143	2,343
144	2,297
145	2,253
146	2,209
147	2,166
148	2,124
149	2,083
150	2,043

Temperature °F	Ω Resistance
151	2,003
152	1,966
153	1,928
154	1,891
155	1,855
156	1,820
157	1,786
158	1,752
159	1,719
160	1,687
161	1,656
162	1,625
163	1,594
164	1,565
165	1,536
166	1,508
167	1,480
168	1,453
169	1,426
170	1,400
171	1,375
172	1,350
173	1,326
174	1,302
175	1,278
176	1,255
177	1,233
178	1,211
179	1,190
180	1,169
181	1,148
182	1,120
183	1,108
184	1,089
185	1,070
186	1,052
187	1,033
188	1,016
189	998
190	981