

Connecting Stranded Wire to Solid Wire

This Supplement Sheet should be use in conjunction with Installation instructions.

Note: Wire nut should be properly sized to join the wires being joined. They should also feature an internal metal spring as shown in the figure below.

Wire Nut



3. Twist wire nut over the two twisted wires. Make sure wire nuts are fastened tight.



1. Strip both solid and stranded wires. The exposed stranded wire should be longer than the exposed wire of the solid.



2. Put wires together and wrap the stranded wire around the solid.



4. Pull stranded wire and wire nut to ensure it does not come loose.