

The new degree of comfort.™

# Rheem *Prestige*<sup>®</sup> Series Communicating Two-Stage Variable Speed Upflow/Horizontal Gas Furnace



## **R802V- Upflow/Horizontal Series**

80% A.F.U.E.† Input Rates 50-125 kBTU



+A.F.U.E. (Annual Fuel Utilization Efficiency) calculated in accordance with Department of Energy test procedures.

- 80% residential Gas Furnace CSA certified
- Two stages of operation to save energy and maintain optimal comfort level.
- Variable speed blower motor technology provides ultimate humidity control quieter sound levels and year round energy savings
- EcoNet enabled HVAC product
- 3 way multi poise design UF / HZ
- PlusOne<sup>™</sup> Diagnostics 7 Segment LED all units
- PlusOne<sup>™</sup> Ignition System DSI for reliability and longevity
- Heat exchanger is removable for improved serviceability. Aluminized steel construction provides maximum corrosion resistance and thermal fatigue reliability.
- · Solid doors provide quiet operation
- Solid bottom


- Insulated blower compartment
- Low profile 34" cabinet ideal for space constrained installations
- · Blower shelf design serviceable in all furnace orientations
- · Hemmed edges on cabinets and doors
- 1/4 turn door knobs for tool less access
- Integrated Control board features dip switches for easy system set up
- QR code for quick access to product information from your smart phone or tablet
- Compatible with single or two stage thermostats. For optimal performance a two stage thermostat is recommended.



# **TABLE OF CONTENTS**

3
4
5
6-7
8
9
10





## **STANDARD EQUIPMENT**

Completely assembled and wired; 2 speed induced draft blower; high and low pressure switches; 2 stage redundant main gas control; blower compartment door safety switch; solid state time on/time off blower control; limit control; transformer; ECM blower motor. Furnaces are equipped with cooling/heating relay and transformer (50VA) ready for air conditioning applications. (Please note: a thermostat is not included as standard equipment.) Flame sensor diagnostics; fusedprotection (secondary), **3rd speed option for continuous fan.** 

## **OPTIONAL EQUIPMENT**

Side and bottom filter frame assembly. 4" Flue Adapter

NOTE: Furnace is not listed for use with fuels other than natural or L.P. (propane) gas.

The complete terms of limited and other warranties are available at our sales office, or through local installer.

All models can be converted by a qualified Rheem distributor or local service dealer to use L.P. (propane) gas without changing burners. Factory approved kits must be used to convert from natural to L.P. (propane) gas and may be ordered as optional accessories from a Rheem parts distributor.

For L.P. (propane) operation, refer to Conversion Kit Index Form. NOTE: For natural and L.P. (propane) gas models, direct spark ignition is 100% safety lockout type.

## WARNING THIS FURNACE IS NOT APPROVED OR RECOMMENDED FOR USE IN MOBILE HOMES





ir Model Features/Physical Data & Specifications R802V (UF/HZ) Series

# **Model Features**

- 80% residential Gas Furnace CSA certified
- Two stages of operation to save energy and maintain optimal comfort level.
- Variable speed blower motor technology provides ultimate humidity control quieter sound levels and year round energy savings
- EcoNet enabled HVAC product
- 3 way multi poise design UF / HZ
- PlusOne<sup>™</sup> Diagnostics 7 Segment LED all units
- PlusOne<sup>™</sup> Ignition System DSI for reliability and longevity
- Heat exchanger is removable for improved serviceability. Aluminized steel construction provides maximum corrosion resistance and thermal fatigue reliability.
- Solid doors provide quiet operation

- Solid bottom
- Insulated blower compartment
- Low profile 34" cabinet ideal for space constrained installations
- Blower shelf design serviceable in all furnace orientations
- · Hemmed edges on cabinets and doors
- 1/4 turn door knobs for tool less access
- Integrated Controls board features dip switches for easy system set up
- QR code for quick access to product information from your smart phone or tablet
- Compatible with single or two stage thermostats. For optimal performance a two stage thermostat is recommended.

## **Physical Data and Specifications**

MODEL NUMBERS R802V SERIES	R802VA050317M*A	R802VA075317M*A	R802VA075421M*A	R802VA100521M*A	R802VA125524M*A
High Input-BTU/Hr [kW] ②	50,000 [15]	75,000 [22]	75,000 [22]	100,000 [29]	125,000 [37]
Heating Capacity BTU/Hr [kW] ①	41,000 [12]	61,000 [18]	61,000 [18]	81,000 [24]	101,000 [30]
Low Input BTU/Hr [kW] ②	35,000 [10]	52,500 [15]	52,500 [15]	70,000 [20]	87,500 [25]
Heating Capacity BTU/Hr [kW] ①	28,000 [8]	42,000 [12]	42,000 [12]	56,000 [16]	70,000 [20]
Heat Ext. Static Pressure [kPa]	.18 [.045]	.20 [.050]	.20 [.050]	.28 [.070]	.28 [.070]
Blower (D x W) [mm]	11 x 7 [279 x 178]	11 x 7 [279 x 178]	11 x 7 [279 x 178]	11 x 10 [279 x 254]	11 x 10 [279 x 254]
Motor H.P. Type [W]	<sup>1</sup> /2 ECM [373]	<sup>1</sup> /2 ECM [373]	<sup>3</sup> /4 ECM [560]	<sup>3/</sup> 4 ECM [560]	<sup>3</sup> /4 ECM [560]
Min. Circuit Ampacity	10	9	13	12	12
Min. Overload Protection Device	15	15	15	15	15
Max. Overload Protection Device	15	15	20	20	15
Max. and Factory Heating CFM [L/s]	890 [420]	1375 [649]	1580 [746]	1580 [746]	1985 [937]
Cooling CFM @ Rating Point [L/s]	1200 [566]	1200 [566]	1600 [755]	2000 [944]	2000 [944]
Max. E.S.P. (In. W.C.) [kPa]	1.0 [.249]	1.0 [.249]	1.0 [.249]	1.0 [.249]	1.0 [.249]
Temperature Rise Range °F [°C]–High Input	25-55 [13.9-30.6]	25-55 [13.9-30.6]	25-55 [13.9-30.6]	35-65 [19.4-36.1]	35-65 [19.4-36.1]
Temperature Rise Range °F [°C]–Low Input	20-50 [12.8-29.4]	20-50 [12.8-29.4]	20-50 [12.8-29.4]	30-60 [18.3-35]	30-60 [18.3-35]
Max. Outlet Air Temp. °F [°C]	155 [68.3]	155 [68.3]	165 [73.8]	180 [82.2]	180 [82.2]
Approx. Shipping Weight (Lbs.) [kg]	125 [57]	125 [57]	140 [64]	140 [64]	150 [68]
AFUE ①	80.0%	80.0%	80.0%	80.0%	80.0%

NOTES: All models are 115V, 60HZ, 1 Ph. Gas connection size for all models is 1/2" [12 mm] N.P.T.

① In accordance with D.O.E. test procedures.


② See Conversion Kit Index Form for high altitude derate.

\* S = Standard, X = Low Nox


# **Model Number Identification**

<u>R</u>	<u>80</u>	<u>2</u>	<u>v</u>	<u>A</u>	075	<u>4</u>	<u>17</u>	Μ	<u>s</u>	<u>A</u>
Rheem	80 = 80% AFUE	2 = Two Stage	V = Variable Speed ECM	Design Series A = 1st Design	Input <u>BTU/HR [kW]</u> 050 = 50,000 [15] 075 = 75,000 [22] 100 = 100,000 [29] 125 = 125,000 [37]	$\begin{array}{l} 3 = Up \ to \\ 3 \ Ton \\ 4 = 2^{1/2} \ to \\ 4 \ Ton \\ 5 = 3^{1/2} \ to \\ 5 \ Ton \end{array}$	Cabinet Width 17 = 17.5" 21 = 21" 24 = 24.5"	M = Multi	X = Low NO <sub>x</sub> S = Standard	Revision- Marketing (A – First Time Release)





# **Upflow Application**






Illustration ST-A1220-04-00 FIGURE 1

## **Dimensional Data: Upflow Model**

MODEL							MINIMUM CLEARANCE (IN.) [mm]					SHIP	
R802V-	A	В	C	D	E	F	LEFT SIDE	RIGHT SIDE	BACK	TOP	FRONT	VENT	WGTS. (LBS.) [kg]
050, 075317	17 <sup>1</sup> /2 [445]	16 <sup>11</sup> /32 [415]	12 <sup>3</sup> /8 [314]	1	15 [381]	21/2 [64]	0	3 [76] 2	0	1 [25]	3 [76]	6 [152] ③	125 [57]
075421, 100	21 [533]	19 <sup>27</sup> /32 [504]	141/8 [359]	1	181/2 [470]	21/2 [64]	0	0	0	1 [25]	3 [76]	6 [152] ③	140 [64]
125	241/2 [622]	2311/32 [593]	157/8 [403]	1	22 [559]	21/2 [64]	0	0	0	1 [25]	3 [76]	6 [152] ③	150 [68]


NOTES: ① May require a 3" [76 mm] to 4" [102 mm] or 3" [76 mm] to 5" [127 mm] adapter.

② May be 0" [0 mm] with type B vent.

③ May be 1" [25 mm] with type B vent.

Furnaces must be vented in accordance with the National Fuel Gas Code, ANSI Z223.1 in accordance with local codes.

## **Horizontal Application**



## **Dimensional Data: Horizontal Model**


MODEL								MINIMUN	I CLEAR	ANCE (IN	.) [mm]		SHIP
R802V-	A	В	C	D	E	F	SUPPLY AIR SIDE	RETURN Air Side	BACK	TOP	FRONT	VENT	WGTS. (LBS.) [kg]
050, 075317	171/2 [445]	16 <sup>11</sup> /32 [415]	123/8 [314]	1	15 [381]	21/2 [64]	3 [76] ②	0	0	1 [25]	3 [76]	6 [152] ③	125 [57]
075421, 100	21 [533]	19 <sup>27/32</sup> [504]	141/8 [359]	1	181/2 [470]	21/2 [64]	0	0	0	1 [25]	3 [76]	6 [152] ③	140 [64]
125	241/2 [622]	2311/32 [593]	157/8 [403]	1	22 [559]	21/2 [64]	0	0	0	1 [25]	3 [76]	6 [152] ③	150 [68]

NOTES: ① May require a 3" [76 mm] to 4" [102 mm] or 3" [76 mm] to 5" [127 mm] adapter.

2 May be 0" [0 mm] with type B vent.

3 May be 1" [25 mm] with type B vent.

Furnaces must be vented in accordance with the National Fuel Gas Code, ANSI Z223.1 in accordance with local codes.



# **Blower Performance Data**

	MODEL N	JMBER		R802VA050317MSA	R802VA075317MSA	R802VA075421MSA	R802VA100521MSA	R802VA125524MSA			
		SW15 = 0FF	SW16 = 0FF	890	1375	1340	1580	1985			
	HIGH	SW15 = 0N	SW16 = 0FF	790	1145	1115	1380	1700			
	HEATING CFM	SW15 = OFF	SW16 = ON			DO NOT USE					
TARGET GAS Heating		SW15 = ON	SW16 = ON	735	1015	980	1260	1530			
AIRFLOW		SW13 = OFF	SW14 = 0FF	835	1077	1030	1390	1500			
	LOW Heating CFM	SW13 = 0N	SW14 = 0FF	590	880	820	1180	1275			
		SW13 = OFF	SW14 = 0N	DO NOT USE							
		SW13 = 0N	SW14 = 0N	510	810	720	1040	1150			
	HIGH	SW4 = OFF	SW5 = OFF	1200	1200	1600	2000	2000			
		SW4 = ON	SW5 = OFF	1000	1000	1400	1600	1600			
TARGET	COOLING CFM	SW4 = OFF	SW5 = 0N	800	800	1200	1400	1400			
COOLING/		SW4 = 0N	SW5 = 0N	600	600	1000	1200	1200			
HEAT-PUMP		SW4 = OFF	SW5 = OFF	900	900	1200	1500	1500			
AIRFLOW	LOW	SW4 = ON	SW5 = OFF	750	750	1050	1200	1200			
	COOLING CFM	SW4 = OFF	SW5 = 0N	600	600	900	1050	1050			
		SW4 = ON	SW5 = 0N	450	450	750	900	900			

Table represents blower performance data without filters.



### SIDE RETURN FILTER RACK: RXGF-CD BOTTOM RETURN FILTER RACK FOR UPFLOW APPLICATION: RXGF-CB

FILTER RACK FILTER SIZES* INCHES [mm]						
MODEL R802V	RXGF-CB (UPFLOW/ HORIZONTAL)	RXGF-CD (UPFLOW) SIDE RETURN				
050 & 075317	15³/4 x 25 [400 x 635]	15 <sup>3/4</sup> x 25 [400 x 635]				
075421 & 100	19 <sup>1/4</sup> x 25 [489 x 635]	15 <sup>3</sup> /4 x 25 [400 x 635]				
125	22 <sup>3</sup> /4 x 25 [578 x 635]	15 <sup>3</sup> /4 x 25 [400 x 635]				

## **INDOOR COIL CASINGS**

	MODEL NUMBER
ſ	RXBC-D17AI
	RXBC-D21AI
ſ	RXBC-D21BI
	RXBC-D24AI

#### 4" FLUE ADAPTER: RXGW-C01

#### WARNING: IMPORTANT NOTICE

A SOLID METAL BASE PLATE (SEE TABLE) MUST BE IN PLACE WHEN THE FURNACE IS INSTALLED WITH SIDE AIR RETURN DUCTS. FAILURE TO INSTALL A BASE PLATE COULD CAUSE PRODUCTS OF COMBUSTION TO BE CIRCULATED INTO THE LIVING SPACE AND CREATE POTENTIALLY HAZARDOUS CONDITIONS.

FURNACE WIDTH IN. [mm]	SOLID Bottom Kit no.	BASE Plate No.	BASE PLATE SIZE IN. [mm]
17 <sup>1</sup> /2 [445] 21 [533]	RXGB-D17 RXGB-D21	AE-61874-02 AE-61874-03	15 <sup>1</sup> /8 x 23 <sup>9</sup> /16 [384 x 598] 18 <sup>5</sup> /8 x 23 <sup>9</sup> /16 [473 x 598]
24 <sup>1</sup> / <sub>2</sub> [622]	RXGB-D24	AE-61874-03	25 <sup>5</sup> /8 x 23 <sup>9</sup> /16 [651 x 598]

## FOR HIGH ALTITUDES:

**OPTION CODE FOR HIGH ALTITUDE:** U.S. None required for high altitudes.

**HIGH ALTITUDE CONVERSION KITS:** U.S. None required for high altitudes.

#### **80+ HIGH ALTITUDE INSTRUCTIONS**

**CAUTION:** Always follow National Fuel Gas Code (NFGC) guidelines when converting for high altitudes.

High altitude option codes are not required for these models. However, the burner orifice size needs to be recalculated and verified at elevations above 2000 ft. See Installation Instructions for more information.

[ ] Designates Metric Conversions

## **ECONET CONTROL**

**RECOMMENDED COMMUNICATING FURNACE CONTROL** 



### **RETST600SYS**

### **CONTRACTOR BENEFITS:**

- Auto/Self Configuration
- Day-at-a-glance scheduling, with programmable fan
- Intuitive wiring connections
- Dual fuel ready
- · Automatically optimizes airflow
- System status & mode information
- · Complete diagnostic information on display

#### **HOMEOWNER BENEFITS:**

- · Large, easy to read icons and characters
- Auto-mode control
- Smart recovery
- Continuous Fan Mode (5 speeds)
- Humidity Control
- Water heater, pool heater integration\* (check model compatibility)


#### \*ECONET CONTROL ACCESSORIES:

Wall Plate = RCPN-AMC08 Face Plate = RETSTFPL

**IMPORTANT:** Existing Comfort Control<sup>2</sup> System Condensing Units & Heat Pumps are compatible with EcoNet when matched with a R802V Gas Furnace and with an EcoNet Translator (RETRN620CC2) installed on the Comfort Control<sup>2</sup> System control board.

\*Available through PROSTOCK®.





# **GENERAL TERMS OF LIMITED WARRANTY\***

Rheem will furnish a replacement for any part of this product which fails in normal use and service within the applicable period stated, in accordance with the terms of the limited warranty.

\*For complete details of the Limited and Conditional Warranties, including applicable terms and conditions, contact your local contractor or the Manufacturer for a copy of the product warranty certificate.

Parts*	Ten (10) Years
Heat ExchangerLi	





In keeping with its policy of continuous progress and product improvement, Rheem reserves the right to make changes without notice.

Rheem Heating, Cooling & Water Heating • P.O. Box 17010 Fort Smith, Arkansas 72917 • www.rheem.com

Rheem Canada Ltd./Ltée • 125 Edgeware Road, Unit 1 Brampton, Ontario • L6Y 0P5