

## **Downflow Gas Furnace**



#### **U802V Downflow Series**

80% A.F.U.E.† Input Rates 75-125 kBTU










†A.F.U.E. (Annual Fuel Utilization Efficiency) calculated in accordance with Department of Energy test procedures.

- 80% residential Gas Furnace CSA certified
- Two stages of operation to save energy and maintain optimal comfort level.
- Variable speed blower motor technology provides ultimate humidity control, quieter sound levels, and year round energy
- EcoNet enabled HVAC product
- PlusOne<sup>™</sup> Diagnostics 7 Segment LED all units
- PlusOne<sup>™</sup> Ignition System DSI for reliability and longevity
- Heat exchanger is removable for improved serviceability. Aluminized steel construction provides maximum corrosion resistance and thermal fatigue reliability.

- Low profile 34" cabinet ideal for space constrained installations
- Integrated Control board features dip switches for easy system
- Insulated blower compartment
- QR code for quick access to product information from your smart phone or tablet
- Compatible with single or two stage thermostats. For optimal performance a two stage thermostat is recommended.

# TABLE OF CONTENTS

Standard & Optional Equipment	3
Model Features/Physical Data & Specifications	4
Model Number Identification	5
Dimensional Data	6
Blower Performance Data	7
Accessories	8
Limited Warranty	9



#### STANDARD EQUIPMENT

Completely assembled and wired; 2 speed induced draft blower; high and low pressure switches; 2 stage redundant main gas control; blower compartment door safety switch; solid state time on/time off blower control; limit control; transformer; ECM blower motor. Furnaces are equipped with cooling/heating relay and transformer (50VA) ready for air conditioning applications. (Please note: a thermostat is not included as standard equipment.) Flame sensor diagnostics; fused-protection (secondary), 3rd speed option for continuous fan.

#### **OPTIONAL EQUIPMENT**

NOTE: Furnace is not listed for use with fuels other than natural or L.P. (propane) gas.

The complete terms of limited and other warranties are available at our sales office, or through local installer.

All models can be converted by a qualified Ruud distributor or local service dealer to use L.P. (propane) gas without changing burners. Factory approved kits must be used to convert from natural to L.P. (propane) gas and may be ordered as optional accessories from a Ruud parts distributor.

For L.P. (propane) operation, refer to Conversion Kit Index Form.

NOTE: For natural and L.P. (propane) gas models, direct spark ignition is 100% lockout type.

## WARNING

THIS FURNACE IS NOT APPROVED OR RECOMMENDED FOR USE IN MOBILE HOMES

#### **Model Features**

- 80% residential Gas Furnace CSA certified
- Two stages of operation to save energy and maintain optimal comfort level.
- Variable speed blower motor technology provides ultimate humidity control, quieter sound levels, and year round energy savings
- EcoNet enabled HVAC product
- PlusOne<sup>™</sup> Diagnostics 7 Segment LED all units
- PlusOne<sup>™</sup> Ignition System DSI for reliability and longevity
- Heat exchanger is removable for improved serviceability.
   Aluminized steel construction provides maximum corrosion resistance and thermal fatigue reliability.

- Low profile 34" cabinet ideal for space constrained installations
- Integrated Controls board features dip switches for easy system set up
- Insulated blower compartment
- QR code for quick access to product information from your smart phone or tablet
- Compatible with single or two stage thermostats. For optimal performance a two stage thermostat is recommended.

#### **Physical Data and Specifications—Downflow Models**

MODEL NUMBERS R802V (DF) SERIES		R802VA075317Z*B	R802VA075421Z*B	R802VA100521Z*B	R802VA125524Z*B	
100% High Input-BTU/Hr [kW] ②		75,000 [22]	75,000 [22]	100,000 [29]	125,000 [37]	
High Heating Capacity-E	STU/Hr [kW] ①	61,000 [18]	62,000 [18]	82,000 [24]	102,000 [30]	
70% Low Input-BTU/Hr	[kW]	52,500 [15]	52,500 [15]	70,000 [20]	87,500 [25]	
Low Heating Capacity–B	TU/Hr [kW]	42,000 [12]	42,000 [12]	56,000 [16]	70,000 [20]	
Heating-Ext. Static Pres	sure [kPa]	.12 [.029]	.12 [.029]	.15 [.037]	.20 [.05]	
Blower (D x W) [mm]		11 x 7 [279 x 178]	11 x 10 [279 x 254]	11 x 10 [279 x 254]	11 x 10 [279 x 254]	
ECM Motor H.P. [W]		1/2 [373]	<sup>3</sup> /4 [559]	1 [746]	1 [746]	
Min. Circuit Ampacity	Min. Circuit Ampacity		11	15	15	
Min. Overload Protection	Min. Overload Protection Device		15 20		20	
Max. Overload Protection	Max. Overload Protection Device		15	20	20	
Factory Heating CFM [L/	Factory Heating CFM [L/s]		1305 [616]	1651 [779]	1998 [943]	
Max Heating CFM [L/s]	Max Heating CFM [L/s]		1774 [837]	2129 [1005]	2308 [1089]	
Cooling CFM @ .5" [kPa] E.S.P. (Nominal) [L/s] (Range)		600-1200 [283]-[566]	1000-1600 [472]-[755]	1200-2000 [566]-[944]	1200-2000 [566]-[944]	
Max. E.S.P. (In. W.C.) [kPa]		0.8 [0.2]	0.8 [0.2]	0.8 [0.2]	0.8 [0.2]	
Temperature Rise	High Fire 30-60 [17-33]		25-55 [14-31]	30-60 [17-33]	35-65 [19.4-36.0]	
Range °F [°C]	Low Fire	20-50 [11-28]	20-50 [11-28]	25-55 [14-31]	30-60 [17-33]	
Max. Outlet Air Temp. °F	Max. Outlet Air Temp. °F [°C]		165 [73.9]	165 [73.9]	185 [85]	
Approx. Shipping Weigh	t (Lbs.) [kg]	115 [52]	115 [52]	120 [54]	140 [63]	
AFUE ①		80%	80%	80%	80%	

Notes: All models are 115V, 60 Hz, 1 Ph. Gas connection size for all models is 1/2" [12 mm] N.P.T.

#### [ ] Designates Metric Conversions

① In accordance with D.O.E. test procedures.


② See Conversion Kit Index Form for high altitude derate in U.S. applications.


## **Model Number Identification—Downflow Models**

<u>U</u>	<u>80</u>	<u>2</u>	<u>v</u>	<u>A</u>	<u>075</u>	<u><b>4</b></u>	<u>17</u>	<u>z</u>	<u>s</u>	<u>A</u>
Ruud	80 = 80% AFUE	2 = Two Stage	V = Variable Speed ECM	Design Series A = 1st Design	Input <u>BTU/HR [kW]</u> 075 = 75,000 [22] 100 = 100,000 [29] 125 = 125,000 [37]	$3 = Up to$ $3 Ton$ $4 = 2^{1/2} to$ $4 Ton$ $5 = 3^{1/2} to$ $5 Ton$	Cabinet Width 17 = 17.5" 21 = 21" 24 = 24.5"	Z = Down and Zero Clearance Downflow	X = Low NOx S = Standard	Revision- Marketing A – First Time Release B – 2nd Design Series

[ ] Designates Metric Conversions

#### **Downflow Dimensions**





## Dimensions and Clearance to Combustible Material (inches) [mm]

						•						
MODEL								REDUCE	D CLEAR	NCES (IN.)	[mm]	
U802V- SERIES	A	В	C	D	E	LEFT SIDE	RIGHT SIDE	BACK	ТОР	FRONT	VENT	SHIP. WGTS. (LBS.) [kg]
075317	17 <sup>1</sup> / <sub>2</sub> [445]	16 <sup>11</sup> /32 [415]	12 <sup>1</sup> /8 [308]	1	16 <sup>5</sup> /8 [422]	0	3 ②	0	1 [25]	3 [76]	6 [152] ③	110 [49.9]
075421	21 [533]	19 <sup>27</sup> / <sub>32</sub> [504]	13 <sup>7</sup> /8 [352]	1	20 <sup>1</sup> /8 [511]	0	0	0	1 [25]	3 [76]	6 [152] ③	115 [52.2]
100	21 [533]	19 <sup>27</sup> / <sub>32</sub> [504]	13 <sup>7</sup> /8 [352]	1	20 <sup>1</sup> /8 [511]	0	0	0	1 [25]	3 [76]	6 [152] ③	120 [54.4]
125	241/2 [622]	2311/32 [593]	155/8 [397]	1	235/8 [600]	0	0	0	1 [25]	3 [76]	6 [152] ③	140 [63.5]

NOTES: ① May require a 3" [76 mm] to 4" [102 mm] or 3" [76 mm] to 5" [127 mm] adapter.

Furnaces must be vented in accordance with the National Fuel Gas Code, ANSI Z223.1 and/or Can/CGA-B149 Installation Codes and in accordance with local codes.

[ ] Designates Metric Conversions

<sup>2</sup> May be 0" [0 mm] with type B vent.

<sup>3</sup> May be 1" [25 mm] with type B vent.

## **Blower Performance Data—Downflow Models**

	MODEL N	UMBER		U802VA075317ZSA	U802VA075421ZSA	U802VA100521ZSA	U802VA125524ZSA			
		SW15 = 0FF	SW16 = 0FF	1254	1305	1651	1998			
	HIGH	SW15 = ON	SW16 = 0FF	1054	1173	1398	1600			
	HEATING CFM	SW15 = 0FF	SW16 = ON	DO NOT USE						
TARGET GAS HEATING		SW15 = ON	SW16 = ON	953	1001	1251	1595			
AIRFLOW		SW13 = 0FF	SW14 = 0FF	980	1125	1300	1480			
	LOW Heating CFM	SW13 = ON	SW14 = 0FF	850	850	1075	1250			
		SW13 = 0FF	SW14 = ON	DO NOT USE						
		SW13 = ON	SW14 = ON	750	700	875	1100			
	HIGH Cooling CFM		SW4 = OFF	SW5 = OFF	1200	1600	2000	2000		
		SW4 = ON	SW5 = OFF	1000	1400	1600	1600			
TARGET		COOLING CFM	SW4 = OFF	SW5 = 0N	800	1200	1400	1400		
COOLING/ HEAT-PUMP AIRFLOW		SW4 = ON	SW5 = 0N	600	1000	1200	1200			
	LOW COOLING CFM	SW4 = OFF	SW5 = OFF	900	1200	1500	1500			
		SW4 = ON	SW5 = OFF	750	1050	1200	1200			
		SW4 = OFF	SW5 = 0N	600	900	1050	1050			
		SW4 = 0N	SW5 = ON	450	750	900	900			

<sup>[ ]</sup> Designates Metric Conversions


#### **DOWNFLOW ACCESSORIES**

DOWNFLOW WARNING: Unit design is certified for installation on noncombustible floor. A special factory supplied combustible floor subbase is required when installing on a combustible floor. Failure to install the sub-base may result in fire, property damage and personal injury.

#### **COMBUSTIBLE FLOOR BASE DIMENSIONS**

COMBUSTIBLE FLOOR BASE	USE WITH FURNACE SIZES	A IN. [mm]	B IN. [mm]	C IN. [mm]
RXGC-B17	U802VA075317	18 [457]	163/4 [425]	143/4 [451]
RXGC-B21	U802VA075421, U802V100	211/2 [546]	201/4 [514]	181/4 [464]
RXGC-B24	U802V125	25 [635]	233/4 [603]	213/4 [552]

#### [ ] Designates Metric Conversions



#### **RXGF-CC\***

FILTER RACK—Downflow top return mount. Requires (2) 14 x 20 Filters.

**NOTE:** Filter racks are shipped without filters.

\*Filters available through PROSTOCK ®.

#### **FOR HIGH ALTITUDES:**

**HIGH ALTITUDE OPTION CODE: U.S.** 

None required for high altitudes.

**HIGH ALTITUDE CONVERSION KITS: U.S.** 

None required for high altitudes.

#### 80+ HIGH ALTITUDE INSTRUCTIONS

Caution: Always follow National Fuel Gas Code (NFGC) guidelines when converting for high altitudes.

High altitude option codes are not required for these models. However, the burner orifice size needs to be recalculated and verified at elevations above 2000 ft. See Installation Instructions for more information.

#### **ECONET CONTROL**

#### RECOMMENDED COMMUNICATING FURNACE CONTROL



**UETST600SYS** 

#### **CONTRACTOR BENEFITS:**

- Auto/Self Configuration
- Day-at-a-glance scheduling, with programmable fan
- Intuitive wiring connections
- · Dual fuel ready
- Automatically optimizes airflow
- · System status & mode information
- · Complete diagnostic information on display

#### **HOMEOWNER BENEFITS:**

- Large, easy to read icons and characters
- Auto-mode control
- · Smart recovery
- Continuous Fan Mode (5 speeds)
- Humidity Control
- Water heater, pool heater integration\* (check model compatibility)

#### \*ECONET CONTROL ACCESSORIES:

Wall Plate = RCPN-AMC08 Face Plate = UETSTFPL

**IMPORTANT:** Existing Comfort Control<sup>2</sup> System Condensing Units & Heat Pumps are compatible with EcoNet when matched with a U802V Gas Furnace and with an EcoNet Translator (RETRN620CC2) installed on the Comfort Control<sup>2</sup> System control board.

\*Available through PROSTOCK®.

## **GENERAL TERMS OF LIMITED WARRANTY\***

Ruud will furnish a replacement for any part of this product which fails in normal use and service within the applicable period stated, in accordance with the terms of the limited warranty.

\*For complete details of the Limited and Conditional Warranties, including applicable terms and conditions, contact your local contractor or the Manufacturer for a copy of the product warranty certificate.

Parts	Ten (10) Years
Heat Exchanger	Limited Lifetime



In keeping with its policy of continuous progress and product improvement, Ruud reserves the right to make changes without notice.

Ruud Heating, Cooling & Water Heating • P.O. Box 17010 Fort Smith, Arkansas 72917 • www.ruud.com Ruud Canada • 125 Edgeware Road, Unit 1 Brampton, Ontario • L6Y 0P5